





[sales@mbt-energy.com](mailto:sales@mbt-energy.com)


# 安装工具



 6mm
  8mm
  10mm
  12mm




 6mm



6-30Nm  
(4.5-22.2lb-ft)

 6mm






≥3.0m




≥6.0m

# 零件列表



U25



C



115




115

100



100


T




80\*80

H40






# 1.安装支架单元



1.1

1 2 3 4



1.2(a)

C 150 M8\*25 T

100


# 1.安装支架单元



1.2(b)

T

100,




1.2(c)

100


T

80


M20\*130




# 1.安装支架单元




1




2



3




4



5


|        |   |         |       |         |  |     |
|--------|---|---------|-------|---------|--|-----|
| 1.2(d) |   |         |       | M20*130 |  | 3-4 |
|        | 1 | 2       | 3     |         |  |     |
| :      |   | M20*130 | 80*80 | M20*130 |  | 4 5 |

# 1.安装支架单元



1.2(e)

## 2.安装轨道



2.1

C



2.2


115

115



115

8


16



## 2.安装轨道




2.5 C                      115                      6mm                      M8  
2 C




2.6  
C


# 3.安装太阳能电池板




1




2




3




4




5




6



7



8



9

3.1a.

135

1

2

b.

135

U25

( 3 4)

c.

135

5

6

d.

7

e.

b/d


U25

8

9

f.

### 3.安装太阳能电池板



3.2

# 质保与售后

/

/

5

10

A A M A

609&610-02

<http://www.aamanet.org>



69

86-592-3754999,86-592-6771595  
sales@mbt-energy.com